

- 2 ss s 0)
- L 1 G)
- ± i)
- G
- G l i
- 1G 1G l 1 L s

OL0044 Chfhs k Vdhfgs Hmchb sn
L G i

1ST 3 s ±
s G s s ±
i s ±
±



DIN Mount



Dash Mount



Trailer Chassis Mount



Gross Vehicle Weight



Net Payload Weight



Stability



Axle Weights

System for 4-, 6- or 8-Wheel Vehicles

WasteWeigh systems incorporate loadcells positioned between the container/body and the vehicle chassis. Weight loaded onto the vehicle is displayed by the in-cab PM1155 digital indicator and is represented by tare, gross and payload information. Printer options provide individual ticket printouts of loaded weight and delivered weight.




- Rear End Loaders
- Front End Loaders
- Hook Loaders
- Roll-On-Offs
- Sludge Tankers
- Recycling Trucks
- Side Loaders



D30945 LOADCELL INSTALLED



SWEDISH 13" LOADCELL INSTALLED



SIDE LIFT LOADERS



SLUDGE TANKER



HOOK LOADER



SKIP TRUCK

All Branches T: 1300 069 970
 NSW (Sydney) T: (02) 9728 4877
 VIC (Melbourne South) T: (03) 9548 5512
 VIC (Melbourne North) T: (03) 9357 7470
 QLD (Brisbane North & South) T: (07) 3265 5520
 WA (Perth) T: (08) 9259 5535
 SA (Adelaide) T: (08) 8447 5011
 New Zealand (Auckland) T: +64 9 951 9685

diverseco.com.au